

A19
12 inch Electric Scooter

User Manual

Thanks for choosing our product. Have fun with this electric scooter.

Contents

1. The Device & Accessories	01
2. Functions	02
3. Assembling	03
4. Charging	03
5. Driving Instructions.....	04
6. Safety instructions.....	05
7. Folding & Transportation	09
8. Daily Maintenance and Storage.....	09
9. Specifications	11
10. Warranty	12

1. The Device & Accessories

Vehicle



Accessories

Screws: 6 pieces for scooter head, and others for front wheel.

Charger: 1 piece


Tool kits: Screw drivers: to assemble the scooter head and front wheel/break.

Tube: 1 as spare part for fix future tube broken(for air tyre).

2. Functions




Dashboard & Power Button



3. Assembling

- 1) Unfold the scooter, make sure hooks well.



- 2) Install scooter handle bar with the 6 screws.
- 3) Assemble the front wheel, adjust the brake system(front wheel is fast assemble design to save shipping cost).
- 4) Testing the power switch after finish assembling.

Power Button

Press power button to turn on the vehicle. Press and hold the button for 2 seconds to turn on the device. When switched on: press power button to turn on/off a flashlight; press a power button twice to switch 4 levels of speed/energy model..

4. Charging

Open the charge port cover, plug the charger into the charge port.

Note! For first time use, please charge the scooter for few hours until the charge light change to Green.


5. Driving Instructions

Warning: Please wear helmet and knee pads when practice.

- 1 .Long press the ON/OFF button on the scooter head to turn the scooter (remember to charge the scooter if scooter battery less than 2 level).
2. Stand on pedal with one leg, hit the ground with the other leg.



3. Step on the other leg when the scooter is moving, then press the accelerate button (only accelerate when the scooter speed is beyond 5km/h). it is kick-start model by default.
4. Loose the accelerate button when slow down. Energy recovery systems will open itself to slow down. Press the brake tightly if want to brake urgently.
5. Lean your body left slightly to turn left, lean your body right slightly to turn right. And turn the handlebar slowly.



6 Safety Instructions

It is not recommended driving on the rain


It is recommended to slightly bend knees to better adjust to a rough road. If you are travelling on a rough road, stick to low speed (5-10km/h)




Entering into any room, elevator, etc.

Be careful not be injured by a door frame.


Please not add speed when descending a hill



While walking with a scooter,
do not press a speed knob



When driving it is recommended to
go around various obstacles on
a road



Please do not hang backpacks and
other heavy objects on handle bars
ground



When driving is forbidden to place
one foot
on the running board or on the




Preventing dangerous driving

It is forbidden to leave a scooter on a scooter wheel at high roadway for motor vehicles or ride in at a high speed



It is forbidden to sharply turn a residential area with a large flow of passers-by



It is forbidden to drive through puddles, to which exceeds depth of 2cm.



Never ride a scooter more than one person, hold a child in your arms.



Safety Recommendations

- 1) Electric scooter - it is only a device for entertainment, not vehicle. But once you driving to public area, the electric scooter brings certain risks for your safety .For the sake of your safety and others safety, you must strictly follow the instructions, outlined in this driving manual.
- 2) You should understand that is you ride a scooter in a public place; you must comply with all recommendations for safety. Also do not forget that there is a possibility of collision, due to violation of pedestrians or vehicles traffic rules, there is also a risk of injury, due to improper operation of the unit. As in other types of vehicles, the higher a speed of electric scooter, the greater a braking distance. On some smooth road emergency braking may cause skidding of scooter, loss of balance and even fall. Therefore, during moving of scooter you need to be vigilant, to adhere to an appropriate speed, keep a safe distance from pedestrians and / or with other vehicles. Riding on unfamiliar terrain, keep vigilance and appropriate speed.
- 3) While riding scooter, respect rights of pedestrians. Do not scare them, especially children. Reduce speed, passing by them. If you are moving in the same direction with pedestrians, try to stick to the left side as much as possible (for right-hand traffic countries). If you are moving in the opposite direction, stick to the right and slow down.
- 4) Please strictly following your country road rules to driving, and also strictly abide by rules, set out in the instructions and safety recommendations.
Violation of the above rules may result financial expenses, personal injury, Occurrence of traffic accidents, legal disputes, conflict and other unpleasant situations. Our company does not bear any direct or joint and several liability.
- 5) To avoid personal injury, do not loan electric scooter to others whom do

not know how to drive. Please spend training before you transfer your scooter to friends, as well as teach he(her) must be wear the proper safety gear .

6) Please do inspect scooter carefully before each use. If you find shattered parts, battery life has decreased obviously, tires leak air or there are signs of excessive wear, uncharacteristic sounds when turning or other abnormal symptoms, please discontinue use of the scooter immediately, don't drive it reluctantly.

7. Fold and Transportation

Make sure scooter be turned off, hold the front pole, fold the scooter.

8. Daily maintenance and and Storage

Clean and store Electric Scooter

If you find any stains on electric scooter housing, use a soft, damp cloth to wipe the vehicle; You can use toothpaste and a toothbrush to clean the scooter from stains, and then wipe it clean with a damp cloth and then clear with a dry cloth. If you find scratched on parts, made of plastic, use sandpaper or other grinding materials for their polishing.

Warning : Do not use alcohol, petrol, kerosene or other corrosive solutions , volatile chemical solvents to clean the vehicle. Otherwise, it will cause serious damage to the scooter body and can disrupt a structure of internal elements. Do not wash electric scooter under a strong pressure of the water, make sure the scooter in the off status. In addition, after charging of the vehicle, it is necessary to insert a plug back to a charging connector, otherwise you may get an electric shock, or may have serious water damage cause from water falling into this hole, may have serious water damage.

If you do not use the scooter, store it in a dry, cool place and do not leave the unit for a long time on the street. Leaving the device under the sun/in extremely high temperature/over-low temperature can cause rapid aging of an outer body and wheels of Electric Scooter or reduce battery life.

Maintenance of Electric Scooter battery

- 1) Do not use batteries from other brands in order to avoid a dangerous situation;
- 2) Do not open or disassemble the battery to prevent electric shock. Avoid contact with metal objects to prevent an occurrence of a short circuit. Otherwise, the battery may have malfunction or can injure the user;
- 3) It is recommended to use an AC adapter, that comes in original configuration of the device, to prevent an occurrence of an accident or fire of the vehicle;
- 4) Improper disposal of used batteries and accumulators is the cause of severe environmental pollution. Please, dispose of batteries in accordance with local laws. Please do not dispose of batteries together with food waste. Protecting the environment together!
- 5) **Warning: After each use of the device, charge the battery to prolong its service life, otherwise the battery may not be able to charge anymore. Full charged scooter could store 5-10 months, but if the battery is used up, it will be only able to store around 1 month!**

Do not store the scooter battery in rooms with temperatures, that exceed 50°C or -20°C (for example, do not leave the battery of Electric Scooter and other batteries in cars in summer time on the hot sun), do not leave the battery near fire. As a result of these actions may deteriorate the battery, overheating and can even cause inflammation.

If within 30 days the scooter is not used, charge the battery and keep the device in a cool, dry place. Every 60 days you need to charge the battery, otherwise there is the likelihood of its failure, which is not subject to warranty services.

Avoid a full discharge of the device, it will extend battery life. When using the device at normal room temperature, the battery will be able to ride much greater distance and its performance will be better; but if you use the scooter at temperatures below 0°C, vehicle performance and permeability decrease.

At -20°C a traveled distance is less, than the scooter in the normal conditions of half or even less. If a temperature rises, a traveled distance by the vehicle will also increase. You can check remaining distance in the Application.

Note: A fully charged scooter runs about 120-180 days of standby time. The battery has a smart chip, that stores information about its charging-discharging. If you are not charging the battery for a long time, it can cause serious damage, for which it is impossible to charge the device again. This kind of damage is not included in free warranty service. (Caution: Do not disassemble the device by unauthorized people, as

there is a risk of electric shock or serious injury as result of a short circuit.

Using a connecting pipe to pump wheels

If a wheel of Electric Scooter deflated, connect a connecting pipe to a wheel nipple to pump it .First, remove the a cap of pin, then tighten a fitting, and then you start to pump a wheel.

9. Specifications

Parameters	
Tyre Size:	12 Inch
Length*Width*Height	121*48*124cm
Folded Length*Width*Height	121*48*54cm
Weight:	Net weight: 21.5kg
Max Load:	120 kg
Age:	16-50
Height(cm)	120-200
Material:	Metal
Max Speed:	<input type="checkbox"/> 20km <input type="checkbox"/> 25km <input type="checkbox"/> 35km <input type="checkbox"/> 40km
Battery:	<input type="checkbox"/> 10ah <input type="checkbox"/> 12.5ah <input type="checkbox"/> 15ah <input type="checkbox"/> 18ah
Motor power:	<input type="checkbox"/> 250W <input type="checkbox"/> 350W <input type="checkbox"/> 500W
Battery Voltage:	<input type="checkbox"/> 36V <input type="checkbox"/> 48V
Charging Voltage:	AC 110-240V, 50-60Hz
Charging Time:	5~8 hours
Operating Temperature:	-10 ~ 40 °C
Storage Temperature:	-20 ~ 45 °C
Power Adaptor:	42V
Charging Time:	5-7 hours
Max Climbing Angles:	10~20°
Certifications:	CE, RoHS, FCC

10. Warranty

I. Warranty service is carried out in accordance with the law on 《consumer rights》 and the 《Law on the quality of products.》 The warranty service includes

Recommendation: use the packaging for safe transport of the device. We recommend keeping the original packaging within 15 days after receipt of goods.

II. Warranty terms

Name	Information on warranty maintenance	Team
Main Unit	Frame, hub motor, controller, steering wheel, handle bar, control panel, rear hub, brakes, Folding system, fork, front fork, governance system bus control, break cable	1 year
Accessories	Battery, Power supply, brake level, switching gears	6 months
Exterior parts that easily wear out	Headlights, instrument cover, handle sets, tires, inner tubes, bell, fender, taillights, stand, battery compartment cover, foot pad, charging port, rubber stopper	3 months

Caution:

Hex wrench, connecting pipe and other consumable component parts have no warranty.

III. Non - warranty regulations

1. Authorized maintenance, misuse, collision, negligence, abuse, intake, accident. Improper use of non-product accessories, or tear up the modified label, anti-counterfeit mark.
2. The warranty period has expired;
3. Damage, caused by force majeure;
4. Failures, which do not correspond to the 《List of faults》
5. A failure of the device or its components from the 《Fault list》, which arose in connection with the human factor, and which interfere with normal operation.
6. Failures, that have arisen in connection with the human factors (including, but not limited to, excessive wetting device, puncture, drop, scratch and damage an outer casing, which have arisen as a result of normal use of goods)
7. If this product is used for commercial purposes, all warranty conditions are not maintained.